


CENTRO™ 6416

LATERAL FILE CABINET

INSTRUCTION MANUAL

LET'S GET STARTED.



DESIGN MATTHEW WEATHERLY

BDi

BDIUSA.COM



Congratulations on the purchase of your Centro Lateral File Cabinet 6416 from BDI. Your file cabinet has been designed to provide a lifetime of enjoyment. This manual will provide you with assembly instructions and other helpful information that will ensure that you get the most out of your product. Please save it for future reference.

Your Centro Lateral File Cabinet has been engineered for simple assembly. Please follow these directions carefully to prevent any damage.

Should you need further assistance, contact BDI at customerservice@bdiusa.com.

ENJOY!

HARDWARE AND COMPONENTS

Unpack and identify the parts listed below. The assembly workspace should be a non-marring surface such as carpet. For missing hardware pieces, please contact BDI Customer Service at customerservice@bdiusa.com.

Do not use power tools for the assembly of this product.

For all other concerns, please contact your BDI retailer.



TOOL REQUIRED (NOT INCLUDED)

Phillips Screwdriver



PART #


T1

DESCRIPTION

Hex Wrench

QUANTITY

1



PART #

H1

DESCRIPTION

1/4-20 x 15mm Screw

QUANTITY

16



PART #

H2

DESCRIPTION

M4 x 37mm Screw

QUANTITY

4



PART #


H3

DESCRIPTION

Bumper

QUANTITY

5



PART #


A1

DESCRIPTION

Cabinet

QUANTITY

1



PART #


C1

DESCRIPTION

Glass Panel

QUANTITY

1



PART #

C2


DESCRIPTION

Pull


QUANTITY

2


HARDWARE AND COMPONENTS




PART #	C3
DESCRIPTION	Base
QUANTITY	2



PART #	C4
DESCRIPTION	Small File Bar
QUANTITY	4




PART #	C5
DESCRIPTION	Large File Bar
QUANTITY	2



PART #	C6
DESCRIPTION	File Bar Clip
QUANTITY	8

Carefully position **(A1) Cabinet** onto its back. Attach both **(C3) Base** to **(A1) Cabinet** using **(H1) Screws** and tighten with **(T1) Hex Wrench**.

	PART/DESCRIPTION	QTY
	T1-HEX WRENCH	1
	H1-SCREW	16





STEP 2. INSTALL BUMPERS & PLACE GLASS PANEL

ASSEMBLY



Carefully position Cabinet onto its base. Remove paper backer from **(H3) Bumpers** and adhere to cabinet as shown.



Place **(C1) Glass Panel** onto the **(A1) Cabinet**. The edge of **(C1) Glass Panel** should be inset $\frac{1}{16}$ " (1.5mm) from the edge of the **(A1) Cabinet**.

	PART/DESCRIPTION	QTY
	H3-BUMPER	5




Attach **(C2) Pulls** using **(H2) Screws** and tighten with a **Phillips Screwdriver**.

	PART/DESCRIPTION	QTY
	H2-SCREW	4
	NOT INCLUDED Phillips Screwdriver	1




For forward facing files, attach **(C6) File Bar Clips** to each end of the **(C4) Small File Bars**. Slide the bars onto the rails so that the **(C6) File Bar Clip** goes into the **groove**.

For **sideways** facing files, **see below**.



For letter files facing sideways, attach **(C6) File Bar Clip** to both ends of **(C5) Large File Bar** as shown. Place the file bar assembly in the notches located on the left and right drawer side panels. For side facing **legal files**, skip this step altogether and hang file folders directly on front and back rails.



CARE & MAINTENANCE

GLASS

The glass surface is maintained using household glass cleaner and a paper towel or cloth.

SATIN-ETCHED GLASS

This uniquely smooth-to-the-touch glass surface can be regularly maintained using household glass cleaner and a paper towel or cloth. Minor scratches or scuffs not eliminated using paper towel or cloth can usually be removed by using a 'Magic Eraser'. Magic Eraser is a melamine foam product available at any grocery store or home improvement center. Dampen the entire glass surface and the Magic Eraser, then rub the entire glass surface in broad, even strokes using moderate pressure. Clean and dry the surface with a paper towel. Check for results and repeat as necessary.

Any scratches or scuffing not eliminated by one of the above methods can often be addressed by 'refreshing' the glass. This is a process that should not be required more than once per 6-12 months. See this brief video for the simple method: www.bdiusa.com/glass

WOOD

Wood surfaces should be cleaned with a slightly damp (not saturated) cloth or paper towel. Do not use glass cleaner on wood. If moisture remains, dry the surface with another cloth. If needed, a gentle non-abrasive cleanser may be used, but be sure to wipe away all cleaner residue and dry the surface with a cloth.

BDI's wood finishes feature natural hardwood solids and veneers. Wood is a product of nature and—unlike man-made materials that can be manufactured to strict and consistent specifications—has natural imperfections that are part of its appeal and character. Every piece of wood differs from every other, even when coming from the very same tree. As such, variation in grain, texture and tone should be expected from one panel or piece of furniture to the next.

While BDI's stained wood finishes are stable in tone & appearance, all finishes are subject to some degree of discoloration with prolonged exposure to direct sunlight. Please take care to avoid positioning your BDI cabinet in any area with extensive direct sunlight. To learn more about the features of natural wood, visit www.bdiusa.com/wood

METAL & PAINTED SURFACES

Surfaces should be cleaned with a slightly damp (not saturated) cloth or paper towel. If moisture remains, dry the surface with another cloth. If needed, a gentle non-abrasive cleanser may be used, but be sure to wipe away all cleaner residue and dry the surface with a cloth.

WARRANTY

BDI warrants to the original purchaser that for the below-stated warranty term, BDI will repair or replace any product, part, or component covered by this warranty that fails under normal use as a result of a defect in material or workmanship. BDI will repair or replace the aforementioned product, part or component with a comparable product, part or component. The decision to repair or replace will be at BDI's sole discretion.

BDI Home Theater Furniture, Office Furniture, Modular Systems, Tables, and other furniture pieces are warranted for three (3) years from the date of purchase as shown on your sales receipt. The warranty period starts from the date of purchase. This warranty extends only to the original purchasers who acquire new products from BDI Authorized Resellers. Any product, part, or component must have been assembled, installed, used, and maintained according to BDI's published instructions to be eligible for warranty coverage. Any modification to the original product voids the warranty.

To view BDI's complete warranty information, visit www.bdiusa.com/warranty

PRODUCT REGISTRATION

Registering your new BDI product allows us to send you important product updates, service information, and helpful hints related to your BDI products. Register today, and you will be entered to win free a BINK table from BDI: www.bdiusa.com/register



WARNING

SERIOUS OR FATAL CRUSHING INJURIES CAN OCCUR FROM FURNITURE TIP-OVER. TO HELP PREVENT TIP-OVER:

- Install tip-over restraint.
- Place heaviest items in lower compartments.
- Never allow children to climb or hang on drawers, doors, or shelves.
- Never open more than one drawer at a time.

USE OF TIP-OVER RESTRAINT MAY REDUCE—BUT NOT ELIMINATE—THE RISK OF TIP-OVER.



BDIUSA.COM

These distinctive product configurations are protected by US and international patents, trade dress, and/or copyright laws. Centro & BDI are trademarks of Becker Designed, Inc. All rights reserved. ©2021, BDI | V.03.18.2021

Made in China.