


CORRIDOR[®] BAR 5620

BAR CABINET

INSTRUCTION MANUAL

LET'S GET STARTED.



DESIGN MATTHEW WEATHERLY

BDi

BDIUSA.COM

Congratulations on the purchase of your Corridor Bar 5620 from BDI. Your cabinet has been designed to provide a lifetime of enjoyment. This manual will provide you with assembly instructions and other helpful information that will ensure that you get the most out of your cabinet. Please save it for future reference.

Your Corridor bar has been engineered for simple assembly. Please follow these directions carefully to prevent any damage.

Should you need further assistance, contact BDI at customerservice@bdiusa.com.

ENJOY!




HARDWARE AND COMPONENTS

Unpack and identify the parts listed below. Note that some components are shipped inside the cabinet. The assembly workspace should be a non-marring surface such as carpet. For missing hardware pieces, please contact BDI Customer Service at customerservice@bdiusa.com.

Do not use power tools for assembly of this product.


For all other concerns, please contact your BDI retailer.




PART #	TI
DESCRIPTION	Phillips Screwdriver
QUANTITY	1



PART #	T2
DESCRIPTION	Hex Wrench
QUANTITY	1




PART #	T3
DESCRIPTION	Open Mouth Wrench
QUANTITY	1



PART #	H1
DESCRIPTION	1/4-20 x 15mm Machine Screw
QUANTITY	12




PART #	H2
DESCRIPTION	1/4-20 x 60mm Machine Screw
QUANTITY	1



PART #	H3
DESCRIPTION	M4 x 25mm Screw
QUANTITY	4




PART #	H5
DESCRIPTION	Rubber Bumper
QUANTITY	5




PART #	H6
DESCRIPTION	Door Pull
QUANTITY	2

HARDWARE AND COMPONENTS



PART #	A
DESCRIPTION	Cabinet
QUANTITY	1



PART #	C1 (right) & C2 (left)
DESCRIPTION	Metal Leg
QUANTITY	1 of each



PART #	C3
DESCRIPTION	Crossbar
QUANTITY	1




PART #	C4
DESCRIPTION	Glass Top
QUANTITY	1

STEP 1. BUILD THE BASE

ASSEMBLY


Slide tab of **(C1 & C2) Metal Legs** into **(C3) Crossbar** and attach with **4 (H1) Screws** and tighten with **(T2) Hex Wrench**.

	PART/DESCRIPTION	QTY
	T2-HEX WRENCH	1
	H1-SCREW	4



Using **8 (H1) Screws** and **1 (H2) Screw**, attach **base assembly** to **(A) Cabinet** with **(T2) Hex Wrench**.
Start all screws before fully tightening all screws.

	PART/DESCRIPTION	QTY
	T2-HEX WRENCH	1
	H1-SCREW	8
	H2-SCREW	1





STEP 3. INSTALL DOOR PULLS AND RUBBER BUMPER


2 PERSON TASK




ASSEMBLY

With help from another person, carefully position **(A) Cabinet** upright and install **(H6) Door Pulls** using **(H3) Screw** and **(T1) Phillips Screwdriver**. Adhere **(H5) Rubber Bumpers** to the top of **(A) Cabinet**.

	PART/DESCRIPTION	QTY
	T1-PHILLIPS SCREWDRIVER	1
	H3-SCREW	4
	H5-RUBBER BUMPER	5



Place **(C4) Glass Top** onto the rubber bumpers on the **(A) Cabinet**. Be sure to place the satin etched side up.





ADJUSTABLE SHELF

The shelf pins located inside the right compartment may be repositioned using **(T1) Phillips Screwdriver**, allowing you to raise or lower the **Adjustable Shelf** to the desired level.

LEVEL CABINET

Once the unit is completely assembled and in its final position, adjust the levelers using **(T3) Open Mouth Wrench** as necessary. If you prefer to have the doors remain in a fully-open position, partially extending the two (2) front levelers is desirable. This action will orient the cabinet back slightly, preventing the open doors from swinging towards their closed position.


	PART/DESCRIPTION	QTY
	T1-PHILLIPS SCREWDRIVER	1
	T3-OPEN MOUTH WRENCH	1



ADJUSTING THE DOOR GAPS

With both doors closed, check to see if the top corners of the doors align. If not, dial out the corresponding front leveler under the door that is sagging.

EXAMPLE: If the door on the right is low, dial out the right front leveler to raise the door back into alignment with the left door.



To move the right door up, dial the front, right leveler out.

To move the left door up, dial the left, front leveler out.

CARE & MAINTENANCE

GLASS

Glass surface is maintained using household glass cleaner and a paper towel or cloth.

SATIN-ETCHED GLASS

This uniquely smooth-to-the-touch glass surface can be regularly maintained using household glass cleaner and a paper towel or cloth. Minor scratches or scuffs not eliminated using paper towel or cloth can usually be removed by using a 'Magic Eraser'. Magic Eraser is a melamine foam product available at any grocery store or home improvement center. Dampen the entire glass surface as well as the Magic Eraser, then rub the entire glass surface in broad, even strokes using moderate pressure. Clean and dry the surface with a paper towel. Check for results and repeat as necessary.

Any scratches or scuffing not eliminated by one of the above methods can often be addressed by 'refreshing' the glass. This is a process that should not be required more than once per 6-12 months. See this brief video for the simple method: www.bdiusa.com/glass

WOOD

Wood surfaces should be cleaned with a slightly damp (not saturated) cloth or paper towel. Do not use glass cleaner on wood. If moisture remains, dry the surface with another cloth. If needed, a gentle non-abrasive cleanser may be used, but be sure to wipe away all cleaner residue and dry the surface with a cloth.

BDI's wood finishes feature natural hardwood solids and veneers. Wood is a product of nature and—unlike man-made materials that can be manufactured to strict and consistent specifications—has natural imperfections that are part of its appeal and character. Every piece of wood differs from every other, even when coming from the very same tree. As such, variation in grain, texture and tone should be expected from one panel or piece of furniture to the next.

While BDI's stained wood finishes are stable in tone & appearance, all finishes are subject to some degree of discoloration with prolonged exposure to direct sunlight. Please take care to avoid positioning your BDI cabinet in any area with extensive direct sunlight. To learn more about the features of natural wood, visit www.bdiusa.com/wood

METAL & PAINTED SURFACES

Surfaces should be cleaned with a slightly damp (not saturated) cloth or paper towel. If moisture remains, dry the surface with another cloth. If needed, a gentle non-abrasive cleanser may be used, but be sure to wipe away all cleaner residue and dry the surface with a cloth.

WARRANTY

BDI warrants to the original purchaser that for the below stated warranty term, BDI will repair or replace any product, part, or component covered by this warranty which fails under normal use as a result of a defect in material or workmanship. BDI will repair or replace the aforementioned product, part or component with a comparable product, part or component. The decision to repair or replace will be at BDI's sole discretion.

BDI Home Theater Furniture, Office Furniture, Modular Systems, Tables and other furniture pieces are warranted for three (3) years from the date of purchase as shown on your sales receipt. The warranty period starts from the date of purchase. This warranty extends only to the original purchasers who acquire new product from BDI Authorized Resellers. Any product, part, or component must have been assembled, installed, used, and maintained according to BDI's published instructions in order to be eligible for warranty coverage. Any modification to the original product voids the warranty.

To view BDI's complete warranty information, visit www.bdiusa.com/warranty

PRODUCT REGISTRATION

Registering your new BDI product allows us to send you important product updates, service information and helpful hints related to your BDI products. Register today, and you will be entered to win free a BINK table from BDI: www.bdiusa.com/register

WARNING

SERIOUS OR FATAL CRUSHING INJURIES CAN OCCUR FROM FURNITURE TIP-OVER. TO HELP PREVENT TIP-OVER:

- Install tip-over restraint.
- Place heaviest items in lower compartments.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time.

USE OF TIP-OVER RESTRAINT MAY REDUCE—BUT NOT ELIMINATE—THE RISK OF TIP-OVER.



These distinctive product configurations are protected by US and international patents, trade dress, and/or copyright laws. Corridor & BDI are trademarks of Becker Designed, Inc. All rights reserved. ©2020, BDI | V.02.22.2022

Made in China.